VIỆT NAM SOLAR
vietnamsolar.vn

DYNESS



DL5.0C Pro

USER MANUAL

Battery Module
51.2V/100Ah

File version-20241114-V1-EN information might be subject to change without notice during product improving.

VIỆT NAM SOLAR
vietnamsolar.vn

Contents

Statement of Law 1
Revision History 1
Safety Precautions 2
Preface 3
Manual Declaration 3
Safety Statement 3
Sign Explanation 3
1 Introduction 4
Brief Introduction 4
Product Properties 4
Product Identity Definition 4
2 Product Specification 6
Size and Weight 6
Performance Parameter 6
Interface Definition 6
Battery Management System(BMS) 14
3 Installation and Configuration 16
Preparation for Installation 16
Equipment Installation 24
4 Use, Maintenance and Troubleshooting 28
Battery System Usage and Operation Instructions 28
Alarm Description and Processing 29
Analysis and Treatment of Common Faults 30

©Dyness reserves the copyright of this document

vietnamsolar.vn

Statement of Law

Copyright of this document belongs to Dyness Digital Energy Technology Co., LTD..

No part of this documentation maybe excerpted, reproduced, translated, annotated or duplicated in any form or by any means without the prior written permission of Dyness Digital Energy Technology Co., LTD..

This product complies with the design requirements of environmental protection and personal safety. The storage, use and disposal of the products shall be carried out in accordance with the product manual, relevant contract or relevant laws and regulations. Customer can check the related information on the website of Dyness Digital Energy Technology Co., LTD. .When the product or technology is updated.

Please note that the product can be modified without prior notification.

Revision History

Revision NO.	Revision Date	Revision Reason
V0	2024.07.31	First Published
V1	2024.11.14	Parameter update
V2	2026.04.01	Adding waterproof cover set

VIỆT NAM SOLAR
vietnamsolar.vn

Safety Precautions

WARNING

Please do not put the battery into water or fire, in case of explosion or any other situation that might endanger your life.

Please connect wires properly while installation, do not reverse connect.

To avoid short circuit, please do not connect positive and negative poles with conductor on the same device.

Please avoid any form of damage to battery, especially stab, hit, trample or strike.

Please shut off the power completely when removing the device or reconnecting wires during the daily use or it could cause the danger of electric shock.

Please use dry powder extinguisher to put out the flame when encountering a fire hazard, liquid extinguisher could result in the risk of explosion.

For your safety, please do not arbitrarily dismantle any component in any circumstances. The maintenance must be implemented by authorized technical personnel or our company's technical support. Device breakdown due to unauthorized operation will not be covered under warranty.

CAUTION

Our products have been strictly inspected before shipment. Please contact us if you find any abnormal phenomena such as device outer case bulging.

The product shall be grounded properly before use in order to ensure your safety.

To assure the proper use please make sure parameters among the relevant device are compatible and matched.

Please do not mixed-use batteries from different manufacturers, different types and models, as well as old and new together.

Ambient and storage method could impact the product life span, please comply with the operation environment instruction to ensure device works in proper condition.

For long-term storage, the battery should be recharged once every 6 months, and the amount of electric charge shall exceed 80% of the rated capacity.

Please charge the battery in 18 hours after it fully discharged or over-discharging protection mode is activated.

Formula of theoretical standby time: T=C/I (T is standby time, C is battery capacity, I is total current of all loads).

The surface of the product cabinet is affixed with a torn invalid label. Therefore, before opening the cover , you need to contact DYNESS and inform the product ID. DYNESS will record this battery ID and authorize the opening operation to

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

be performed. Except for changing the DIP switch mode, no other operations are allowed. In the next stage, you can log in to apply for operations directly on the DYNESS website. Contact the authorized dealer or distributor of DYNESS for a new torn invalid sticker after tearing the original invalid label. When the operation is completed, paste the new one at a different position.

Preface

Manual Declaration

DL5.0C Pro lithium iron phosphate battery energy storage system can provide energy storage for photovoltaic power generation users through parallel combination. Our product can store extra electricity into battery from photovoltaic power generation system in daytime and supply stable power to user's equipment as power backup at nighttime or any time when needed. It can improve the efficiency of photovoltaic power generation and increase the electric power efficiency by peak load shifting.

This user manual details the basic structure, parameters, basic procedures and methods of installation and operation and maintenance of the equipment.

Safety Statement

Only qualified trained professionals are allowed to install, operate, maintain the device.

Please comply with local safety regulations and operational rules during installation, operation and maintenance, or it could cause unexpected injury or device damage.

The safety declaration mentioned in the manual are only supplement context for your local safety regulations.

The seller does not undertake any responsibility for device operations or usage of violating general safety requirements and safety standards.

If a fire breaks out, use a dry powder fire extinguisher.

Sign Explanation

User should understand the meaning of the caution sign below when configuring or operating series products.

⚠ CAUTION

Neglecting the warnings might cause equipment failure.

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

1 Introduction

Brief Introduction

DL5.0C Pro lithium iron phosphate battery system is a standard battery system unit, customers can choose a certain number of DL5.0C Pro according to their needs, by connecting parallel to form a larger capacity battery pack, to meet the user's long-term power supply needs. The product is especially suitable for energy storage applications with high operating temperatures, limited installation space, long power backup time and long service life.

Product Properties

DL5.0C Pro energy storage product's positive electrode materials are lithium iron phosphate, battery cells are managed effectively by BMS with better performance, the system's features as below:

- Comply with European ROHS, Certified SGS, employ non-toxic, non-pollution environment-friendly battery.
- Anode materials are lithium iron phosphate (LiFePO4), safer with longer life span.
- Carries battery management system with better performance, possesses protection function like over-discharge, over-charge, over-current, abnormal temperature.
- Self-management on charging and discharging, Single core balancing function.
- Intelligent design configures integrated inspection module.
- Flexible configurations allow parallel of multi battery for longer standby time.
- Self-ventilation with lower system noise.
- Less battery self-discharge, then recharging period can be up to 10 months during the storage.
- No memory effect so that battery can be charged and discharged shallowly.
- With wide range of temperature for working environment, -20°C to +55°C, circulation span and discharging performance are well under high temperature.
- Less volume, lighter weight.

Product Identity Definition

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn




Figure 1-1 Battery Module Label



Figure 1-2 Heating function Label

(Only systems with heating function will be labeled with this label)

Table 1-1 Symbol Definition

	After the battery life is terminated, the battery can continue to be used after it recycled by the professional recycling organization and do not discard it at will.
	The scrapped battery cannot be put into the garbage can and must be professionally recycled.
	Read the user manual before using.
	Inflammable.
	Battery voltage is higher than safe voltage, direct contact with electric shock hazard.
	Do not place near open flame or incinerate.

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

	If catch fire, do not put out with water.
	Do not misappropriate or occupy fire-fighting equipment.
	Do not cut or spear with sharp objects.
	This battery product meets European directive requirements.

2 Product Specification

Size and Weight

Table 2-1 DL5.0C Pro Device size

Product	Nominal Voltage	Nominal Capacity	Dimension	Weight
DL5.0C Pro	DC51.2V	100Ah	488×515×150mm	46kg

Performance Parameter

Table 2-2 DL5.0C Pro performance parameter

Item	Parameter value
Nominal Voltage(Vdc)	51.2
Work Voltage Range(Vdc)	44.8 to 57.6
Nominal Capacity(Ah)	100
Nominal Energy(kWh)	5.12
Recommended Charge/Discharge Current (A)	50
Max Power Continuous Charge Current (A)	75
Max Power Continuous Discharge Current (A)	100
Peak Power Charge/Discharge Current (A)	200 (2min)
Recommend Charge Voltage (Vdc)	56.5

Interface Definition

This section elaborates the interface functions of the front interface of the device.

`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn




Figure 2-1 The Sketch of Interface

Table 2-3 Interface Definition

Item	Name	Definition
1	Positive socket	Battery output positive or parallel positive line
2	ADD	DIP switch
3	SW (battery wake/sleep switch)	When the "OFF/ON" switch button is in the ON state, press and hold this button for 3 seconds to put the battery into the power-on or off state.
4	SOC	The number of green lights shows the remaining power. Table 2-7 for details.
5	ALM	Red light flashing when an alarm occurs, red light always on during protection status. After the condition of trigger protection is relieved, it can be automatically closed.
6	RUN	Green light flashing during standby and charging mode. Green light always on when discharging.
7	CAN	Communication cascade port, support CAN communication (factory default CAN communication)
8	485	Communication cascade port, support RS485
9	DRY CONTACT	/
10	Negative socket	Battery output negative or parallel negative line
11	Grounding	Shell ground connection
12	Power switch	OFF/ON, must be in the "ON" state when in use

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Item	Name	Definition
13	Wifi	Remote upgrade program
14	LED light	Display battery SOC and warning information

Table 2-4 DIP switch definition and description

DIP switch position (master communication protocol and baud rate selection)			
#1	#2	#3	#4
Define different protocols; Distinguish between master and slave			Baud rate selection
			OFF：CAN: 500K,485: 9600
			ON：CAN: 250K,485: 115200

`©Dyness reserves the copyright of this document

vietnamsolar.vn

DIP Switch Description

When the batteries are connected in parallel, the host communicates with the slaves through the CAN interface. The host summarizes the information of the entire battery system and communicates with the inverter through CAN or 485.

If the master is the latest DL5.0C Pro battery with DIP switch:


1. The communication cable from the master CAN IN to the inverter comm port should be the correct one.

2. When the battery works with SMA、Victron、Ingeteam、Solis、GOODWE、Solplanet、SOFAR、SAJ、Deye、Hoymiles、APsystems、SOLAX、LUXPOWER、MUST、SOSEN、TBB、Afore inverters, before starting the battery, you need to put the master DIP switch "# 3" to the "ON" position (to the top), then turn on the batteries.



Master Setting 1

3. If the battery communicates with the Axpert-king/VMIII/MAX, Infinisolar, Growatt SPH/SPA(CAN comm) , turn the master DIP switch "#2" to "ON" position.



Master Setting 2

4. If the battery communicates with the Growatt SPF HVM-P/ES/WPV by RS485 communication, turn the master DIP switch "#2" and "#3" to "ON".




Master Setting 3

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

5. If the battery communicates with the Schneider Conext Series, turn the master DIP switch "#1" and "#3" to "ON".



Master Setting 4


6. When you setup the master DIP as setting 1 to 4, all the slaves keep the DIP 0000,no need to change.

7. If the energy storage system has only one DL5.0C Pro, it is the master itself, and still follow the above steps.

Note: For more information of matching inverter brands, please subject to the latest document

<The list of compatibility between Dyness ESS and Inverters >.

CAN IN CAN OUT



Plug Socket of communication

Figure 2-2 CAN Interface Definition

`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Table 2-5 Pin Definition

Foot position	Color	Definition
PIN1	Orange/white	Reserve
PIN2	Orange	Reserve
PIN3	Green/white	Reserve
PIN4	Blue	EXT CANH
PIN5	Blue/white	EXT CANL
PIN6	Green	Reserve
PIN7	Brown/white	INT CANH
PIN8	Brown	INT CANL
PIN9	Orange/white	Reserve
PIN10	Orange	Reserve
PIN11	Green/white	Reserve
PIN12	Blue	Reserve
PIN13	Blue/white	Reserve
PIN14	Green	Reserve
PIN15	Brown/white	INT CANH
PIN16	Brown	INT CANL




Figure 2-3 485 Interface Definition

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Table 2-6 485 Interface Definition

Foot position	Definition
PIN1	485B
PIN2	485A
PIN3	Reserve
PIN4	Reserve
PIN5	Reserve
PIN6	Reserve
PIN7	Reserve
PIN8	Reserve

Tips: Please pay attention of the communication com definition of inverter, in order to avoid voltage in the port to affect communication.

Table 2-7 LED Status Indicators

Battery Status	SOC(%)	LED 1	LED 2	LED 3	LED 4	LED5	ALM	RUN
Shutd-own	/	off	off	off	off	off	off	off
Standby	80%≤SOC≤100 %	●	●	●	●	●	off	Flashing
	60%≤SOC＜ 80%	●	●	●	●	off	off	Flashing
	40%≤SOC＜ 60%	●	●	●	off	off	off	Flashing
	20%≤SOC＜ 40%	●	●	off	off	off	off	Flashing
	0%＜SOC＜ 20%	●	off	off	off	off	off	Flashing
	SOC=0	off	off	off	off	off	off	Flashing
Charging	80%≤SOC≤100 %	●	●	●	●	Flashi ng	off	Flashing
	60%≤SOC＜	●	●	●	Flashi	off	off	Flashing

`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Battery Status	SOC(%)	LED 1	LED 2	LED 3	LED 4	LED5	ALM	RUN
	80%				ng			
	40%≤SOC＜60%	●	●	Flashing	off	off	off	Flashing
	20%≤SOC＜40%	●	Flashing	off	off	off	off	Flashing
	0%＜SOC＜20%	Flashing	off	off	off	off	off	Flashing
	SOC=0	Flashing	off	off	off	off	off	Flashing
Dischar-ging	80%≤SOC≤100%	●	●	●	●	●	off	●
	60%≤SOC＜80%	●	●	●	●	off	off	●
	40%≤SOC＜60%	●	●	●	off	off	off	●
	20%≤SOC＜40%	●	●	off	off	off	off	●
	0%＜SOC＜20%	●	off	off	off	off	off	●
	SOC=0	off	off	off	off	off	off	●

A special ALM light flashing state: when the communication between batteries is lost or abnormal,all the lights from SOC to RUN of the master battery will flash together.

●: means green light always on

Flashing: means green light flashing

Table 2-8 Front LED Status Indicators

LED status	Information
	SOC 50%
	SOC 100%

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Current SOC increases to 100% ,then cycles 	Charge
Drop from current SOC to 0%, then loop 	Discharge
Green light flashing(Current SOC) 	Standby
Yellow light flashing	Communication failure between batteries or communication failure between lamp board and BMS
Red light on 	System protection

Battery Management System(BMS)

Voltage Protection

Low Voltage Protection in Discharging:

When any battery cell voltage or total voltage is lower than the rated protection value during discharging, the over-discharging protection is activated, and the battery buzzer makes an alarm sound. Then battery system stops supplying power to the outside. When the voltage of each cell back to rated return range, the protection is over.

Over Voltage Protection in Charging：

Battery will stops charging when total voltage or any battery cell voltage reaches the rated protection value during charging stage. When total voltage or all cell back to rated range, the protection is over.

Current Protection

Over Current Protection in Charging：

When the charge current＞90A, current limit protection mode is activated, current will be limited to≤3A， protection is removed after rated time delaying 10S. Circulate like this until the current is lower than 90A.

Over Current Protection in Discharging：

When the discharge current is higher than 125A, the battery buzzer alarms and the system stops discharging. After protection, the discharging will restore in 60s delay or immediately when there is charging current.

`©Dyness reserves the copyright of this document

vietnamsolar.vn

CAUTION

The buzzer sound alarm setting can be manually turned off on the background software, and the factory default is on.

Temperature Protection

Low/Over temperature protection in charging：

When battery's temperature is beyond range of 0°C to +65°C during charging, temperature protection is activated, device stops charging.

The protection is over when temperature back to rated working range.

CAUTION

If you choose a product with heating function, the charging temperature range is -20°C to 65°C.

Low/Over temperature protection in discharging：

When battery's temperature is beyond range of -20°C to +65°C during discharging, temperature protection is activated, device stops supplying power to the outside.

The protection is over when temperature back to rated working range.

Other Protection

Short Circuit Protection：

When the battery is activated from the shutdown state, if a short circuit occurs, the system starts short-circuit protection for 60 seconds.

Self-Shutdown：

When device connects no external loads and power supply and no external communication for over 72 hours, device will dormant standby automatically.

CAUTION

Battery's maximum discharging current should be more than load's maximum working current.

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

3 Installation and Configuration


Preparation for installation

Safety Requirement

This system can only be installed by personnel who have been trained in the power supply system and have sufficient knowledge of the power system.

The safety regulations and local safety regulations listed below should always be followed during the installation.

- All circuits connected to this power system with an external voltage of less than 51.2V must meet the SELV requirements defined in the IEC60950 standard.
- If operating within the power system cabinet, make sure the power system is not charged. Battery devices should also be switched off.
- Distribution cable wiring should be reasonable and has the protective measures to avoid touching these cables while operating power equipment.
- The following protective items must be worn when installing the battery system:



Insulated Gloves Safety Goggles Safety Shoes

Figure 3-1 Safety Gear

Environmental requirements

Charging temperature range is 0°C to +55°C (Products without heating function)

Charging temperature range is -20°C to +55°C (Products with heating function)

Discharging temperature range is -20°C to +55°C

Storage temperature: -10°C to +35°C

Relative humidity: 5% to 85%RH

Elevation: no more than 4000 m

Operating environment: Indoor installation, sites avoid the sun and no wind, no conductive dust and corrosive gas.

And the following conditions are met:

`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

- Installation location should be away from the sea to avoid brine and high humidity environment.
- The ground for product arrangement shall be flat and level.
- No flammable explosive materials near the installation site.
- The optimal ambient temperature is 15°C to 30°C.
- Keep away from dust and messy zones.

Tools and data

Tools and meters that may be used are shown in Figure 3-2 Installation Tools.




Figure 3-2 Installation Tools

Technical preparation

Electrical interface check

Devices that can be connected directly to the battery can be user equipment, power supplies, or other power supplies.

- Confirm whether the user's PV power generation equipment, power supply or other power supply equipment has a DC output interface, and measure whether the DC power output voltage meets the voltage range requirements in Table 2-2.
- Confirm that the maximum discharge current capability of the DC power interface of the user's photovoltaic power generation equipment, power supply or other power supply equipment should be less than the maximum charging current of the products used in Table 2-2.
- If the maximum discharge capability of the DC power interface of the user's photovoltaic power generation equipment is higher than the maximum charging current of the products used in Table 2-2, the DC power interface of the user's photovoltaic power generation equipment shall have a current limiting function to ensure the normal operation of the user's equipment.

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

- Verify that the maximum operating current of the battery-powered user equipment (inverter DC input) should be less than the maximum discharge current of the products used in Table 2-2.

The security check

- Firefighting equipment should be provided near the product, such as portable dry powder fire extinguisher.
- Automatic fire fighting system shall be provided for the case where necessary.
- No flammable, explosive and other dangerous materials are placed beside the battery.

Unpacking Inspection

- When the equipment arrives at the installation site, loading and unloading should be carried out according to the rules and regulations, to prevent from being exposed to sun and rain.
- Before unpacking, the total number of packages shall be indicated according to the shipping list attached to each package, and the case shall be checked for good condition.
- In the process of unpacking, handle with care and protect the surface coating of the object.
- Open the package, the installation personnel should read the technical documents, verify the list, according to the configuration table and packing list, ensure objects are complete and intact, if the internal packing is damaged, should be examined and recorded in detail.

Table 3-1 Packing List 1


Item	Specification	Quantity	Figure
Battery	51.2V/100Ah	1	
Wall Bracket	SGCC T3.0	1	
Power cable-positive	Red /4AWG/L1500mm	1	
Power cable-negative	Black /4AWG/L1500mm	1	
Communication parallel cable	Black /L2000mm/Double RJ45 plug	1	

`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Communication cable-to inverter	Black /L2000mm /Double RJ45 plug	1	
Ground wire	L500mm,4mm²	1	
Screws With Shoulder	Screws M8	4	
Expansion Bolt	M6*80	4	
Positioning cardboard	/	1	
User Manual	User Manual	1	
Letter to customer	/	1	
Warranty card	/	1	
Packing list	/	1	

Table 3-2 Packing List 2 *

Waterproof cover set	/	1	

*Note: optional.

Engineering coordination

Attention should be paid to the following items before construction:

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Power line specification.

- The power line specification shall meet the requirements of maximum discharge current for each product.
- Mounting space and bearing capacity.
- Make sure that the battery has enough room to install, and that the brackets have enough load capacity.

Wiring.

- Make sure the power line and ground wire are reasonable. Not easy to short-circuit, water and corrosion.

Installation Preparation

1. Prepare equipment and tools for installation.

2. Check the DL5.0C Pro unit and confirm that the ON/OFF switch is in the "OFF" state to ensure the device is shut off.

`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Wall hanging Installation method:

1.Use the positioning cardboard (provided in accessory package) and mark the screw hole positions on the wall. Shown as below.




Figure 3-3

2.The cardboard must be perpendicular to the ground while drawing the holes.

3.The bottom of the cardboard is about 300mm from the ground.The customer decides the installation height based on the usage environment.

4.According to the position of the mark, 4 holes in diameter 10mm and depth of more than 70mm are hit on the wall with an electric drill, which are used for fitting expansion bolt.




Figure 3-4

5.Fixing the Support bracket on the wall with M6 bolts. Twisting force keeps 10N·m.




Figure 3-5

6.Install the step screws into the screw holes on the rear of the battery case.

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn




Figure 3-6

7.Transport the battery to the installation site and hang it on the bracket.




Figure 3-7

Floor Standing Installation Method:

When the battery system is placed directly on the ground, a fixed support must be used to fix the top of the battery box on the wall

1.Use the positioning cardboard (provided in accessory package) and mark the screw hole positions on the wall, as shown four holes in the picture on the left.




Figure 3-8

2.Repeat the wall installation steps 4-7

`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Installing the Waterproof Cover Set

Appearance




Figure 3-9

1	Snap-Fit
2	Groove
3	Cable Outlet

Installation Steps

1. Fit the waterproof housing onto the battery.
2. After wiring, install the waterproof cover.
3. Press down until a "click" is heard.






Figure 3-10

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Equipment Installation


Table 3-2 Installation steps

Step 1 Installation preparation
Confirm that the ON/OFF switch on the front panel of DL5.0C Pro unit is in the “OFF” state to ensure no live operation. OFF 
Step 2 Mechanical installation
1. Battery placement position determination 2. Battery module installation
Step 3 Electrical installation
1. Ground cable installation  2. Battery module parallel cable installation(Refer to Figure 3-9) 3. Parallel communication cable connection(Refer to Figure 3-9)
Step 4 Battery system self-test
1. Turn the ON/OFF switch to the "ON" state. ON  2. Press SW button 3secs to wake up battery.  3. Check the system output voltage and led status  4. Shut down the system
Step 5 Connecting inverter


`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

1. Connect total positive & total negative cable of the battery system to the DC breaker.
2. Close the DC breaker between inverter and battery
3. Connect the DC breaker to the inverter.
4. Connect the communication cable from the master CAN IN to the inverter.



5. Turn on the Power switch and wake up system by SW button.



6. Turn on the DC breaker between inverter and battery.
7. Turn on the inverter and check the communication between inverter and battery system.

Electrical installation

Before connecting the power cables, use multimeter to measure cable continuity, short circuit, confirm positive and negative, and accurately mark the cable labels.

Measuring methods:

Power cable check: select the buzzer mode of multimeter and detect the both ends of the same color cable. If the buzzer calls, it means the cable is in good condition.

Short circuit judgment: choose multimeter resistor file, probe the same end of positive and negative pole, if the resistor shows infinity, means that the cable is available.

After visual testing of power line connection, the positive and negative poles of the battery shall be connected respectively to the positive and negative poles of the opposite terminal.

It is better to add a circuit breaker between the inverter and the battery system. The selection of the circuit breaker requires:

Voltage: U>60V

Current: I =Inverter power/45V

The circuit breaker is installed between the battery module and the inverter, as shown in Figure 3-9:

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn




Figure 3-9

`©Dyness reserves the copyright of this document

vietnamsolar.vn

Note:

1. For more ADD Settings， please refer to P8 “DIP switch definition and description”
2. After the whole system connection, set the master DIP mode according to the inverter model firstly, then start the battery.
3. The BAT-INV communication cable is from inverter comm port to master CAN IN port, BAT-BAT cable is from master CAN OUT to slave1 CAN IN, slave1 CAN OUT to slave2 CAN IN...
4. The limited continuous current for each pair of power cable is 120A. Please add power cable according to the proportion if the max. working current of the inverter is more than 120A.

Battery parameter settings on the inverter

Max Charging(Bulk) Voltage: 56.5V

Absorption Voltage: 56V

Float Voltage: 55.5V

Shut Down(cut off) Voltage: 48 to 50V

Shut Down(cut off) SOC: 5%

Restart Voltage: 52V

Recommended Charge Current : 50A*BATTERY Qty
Recommended Discharge Current : 50A*BATTERY Qty

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

4 Use, Maintenance and Troubleshooting

Battery System Usage and Operation Instructions

After completing the electrical installation, follow these steps to start the battery system.

Refer to P8 DIP Switch Description to prepare the battery module before starting up, then press the ON/OFF button to the ON position, press and hold the SW button for 3 seconds.

After the indicator self-test, the RUN indicator will light and the SOC indicator will be on




Figure 4-1

CAUTION

After pressing the power button, if the battery status indicator on the front panel continues to be red, please refer to the "P24 Alarm description and processing ". If the failure cannot be eliminated, please contact the dealer timely.

Use a voltmeter to measure whether the voltage of the circuit breaker battery access terminal is higher than 44.8V, and check whether the voltage polarity is consistent with the inverter input polarity. If the circuit breaker battery input terminal has a voltage output and is greater than 44.8V, then the battery begun to work normally.

After confirming that the battery output voltage and polarity are correct, turn on the inverter, close the circuit breaker.

Check if the indicator of the inverter and battery connection (communication indicator and battery access status indicator) is normal. If it is normal, successfully complete the connection between the battery and the inverter. If the indicator light is abnormal, please refer to the inverter manual for the cause or contact the dealer.

`©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Alarm Description and Processing

When protection mode is activated or system failure occurred, the alarm signal will be given through the working status indicator on the front panel of the DL5.0C Pro. The network management can query the specific alarm categories.

If the fault such as single cell over voltage, charging over-current, under-voltage protection, high-temp protection and other abnormalities which affects the output, please deal with it according to Table 4-1.

Table 4-1 Main Alarm and Protection

Statue	Alarm category	Alarm indication	Processing
Charge state	Over-current	RED Buzzer start	Stop charging and find out the cause of the trouble
	High temp	RED	Stop charging
Discharge state	Over-current	RED Buzzer start	Stop discharging and find out the cause of the trouble
	High temp	RED	Stop discharging and find out the cause of the trouble
	Total voltage undervoltage	RED Buzzer start	Start charging
	Cell voltage undervoltage	RED Buzzer start	Start charging

©Dyness reserves the copyright of this document

VIỆT NAM SOLAR
vietnamsolar.vn

Analysis and Treatment of Common Faults

Analysis and treatment of common faults in the Table 4-2:

Table 4-1 Analysis and Treatment of Common Faults

No.	Fault phenomenon	Reason analysis	Solution
1	The indicator does not respond after the power on	Total voltage lower than 35V	Check the total voltage
2	No DC output	Battery data status is abnormal. Battery gets into over-discharged protection	Read the battery information on the monitor.
3	The DC power supply time is too short	Battery capacity become smaller	Storage battery replacement or add more modules
4	The battery can't be fully charged to 100%	Charging voltage is too low	Adjust charging voltage at 56.5V or 57V
5	The power cable sparks once power on and ALM light RED	Power connection short-circuit	Turn off the battery, check the cause of the short circuit
6	Communication fault	The DIP setting of the host is wrong/ the battery type of the inverter is wrong/ Communication cable used incorrectly/The communication cable is incorrectly connected at the battery communication port or the inverter communication port/The battery firmware version is too low to support the inverter	Check these possible causes one by one

If you need any technical help or have any question, please contact the dealer. I

`©Dyness reserves the copyright of this document

vietnamsolar.vn

Address: Building 1&2,7th–8th Floors, Building 3,No. 58 Nanhu Road,Chengnan Subdistrict,
Wuzhong District, Suzhou City, Jiangsu Province
Email: service@dyness-tech.com
Tel: +86 400 666 0655
Web: www.dyness.com

Official Website

©Dyness reserves the copyright of this document